

FD Series Fire Damper

Installation, Maintenance and Operating Instructions

Installation:

1. Before installation, the damper should be inspected to ensure that it has not been damaged and is in good condition following transportation.
2. Ensure that all packing materials are removed, as failure to complete could result in permanent damage to the product. Also ensure the “ tape “ is removed from the Fusible Link.
3. Ensure that the ductwork and damper spigots are carefully matched, with the specified sealing material used during installation.
4. Ensure that the ductwork is adequately supported, this is particularly important where large dampers are concerned.
5. Ensure that the damper is free of any foreign matter, the assembly is not distorted and is square with no surface damage that could restrict blade movement.
6. If stored before installation, ensure the product is stacked and stored in clean, dry conditions to prevent the ingress of dust, as well as avoiding excessive temperatures or humidity.
7. Care should always be taken when handling dampers on site to avoid subjecting them to excessive stresses for which they are not designed.
8. When installed, operate the damper blades by disconnecting the Fusible-Link, particular attention must be given when re-setting the Fusible Link correctly into its latches.
9. It is important to ensure that all dampers are installed with airflows and pressures conforming to the test data as detailed in the manufacturers technical product manual. Excessive airflows and/or pressures could result in permanent damage and/or malfunction of the damper.

Special Note :

All Firedamper installations must be carried out to the satisfaction of the appropriate district surveyor, fire officer, and/or specifying authority as other approved methods of installation may well be used.

It is important to ensure that the installation is in conformance to the relevant building codes of practice that are current at time of installation, ie HVCA's DW 144.

FD Series Fire Damper

Installation, Maintenance and Operating Instructions

Maintenance :

Page 2 Continued...

1. Keep the damper clean and free from any contamination or foreign items.
2. Where possible operate the blades against airflow to ensure easy, free movement.
3. Periodic inspection should be made of the damper, to ensure efficient operation, in addition to its installation, ie Walls, Partitions or Floors.
4. It is recommended within normal preventative maintenance procedures for the blades and inner casings to be cleaned annually, as well as inspection of Closure Springs and the Fusible Link.
5. Use of Oils is not recommended, due to the possible build-up of dust.
6. It is recommended to check regularly the operation of Micro-Switches, Solenoids, Electro-Magnets and other secondary Actuators, to ensure correct operation.
7. The time period can best be ascertained by experience or local regulations, but should not exceed a twelve month interval. Inspection should be carried out more frequently where excessive dust or dirty conditions prevail.

Operation :

1. These dampers are primarily designed for use in ductwork systems to stop the spread of Fire or Flames.
2. It is assumed that the airflow through the damper is filtered and environmentally controlled, with regard to humidification and corrosive atmospheres to National and International Specifications.

National and International Specifications :

1. The F.D. Series Firedamper is designed and manufactured for use as described in the HVCA Ductwork Specification DW 144, and as Eurovent 2/2.
2. This product does conform to other National and International Specifications not mentioned above, B.S.B.'s sales office can confirm detail as required.

Recommended Spares :

1. A quantity of Fusible Links to the specified temperature rating.
2. Consideration to a quantity of Solenoids, Electro-Magnets and/or other Electrical Components should be made with regard to large projects.

It is always recommended that if either the specifying authority, the installer or the user has any doubts with regard to product selection and/or suitability to the application, then contact to the following office is advised.

B.S.B. Engineering Services Ltd.

(Technical Sales Department).

Unit E , Tribune Drive,

Trinity Trading Estate,

Sittingbourne.

Kent ME10 2PD.

Tele # +44 (0) 1795 422609.

Fax # +44 (0) 1795 429543.

Email: sales@bsb-dampers.co.uk

www.bsb-dampers.co.uk