

# **BD Series Backdraft Dampers**

## **Installation, Maintenance and Operating Instructions**

### **Models: Flangefit, Framefit and Spigotfit**

#### **Installation:**

1. Before installation, the damper should be inspected to ensure that it has not been damaged and is in good condition following transportation.
2. Ensure that all packing materials are removed, as failure to complete could result in permanent damage to the product.
3. Ensure that the ductwork and damper flange or spigots are carefully matched, with the specified sealing material used during installation.
4. Ensure that the ductwork is adequately supported, this is particularly important where large dampers are concerned.
5. Ensure that the damper is free of any foreign matter, the assembly is not distorted and is square with no surface damage that could restrict blade movement.
6. If stored before installation, ensure the product is stacked and stored in clean, dry conditions to prevent the ingress of dust, as well as avoiding excessive temperature or humidity.
7. Care should always be taken when handling dampers on site to avoid subjecting them to excessive stresses for which they are not designed.
8. It is important to ensure that all dampers are installed with airflows and pressures conforming to the test data as detailed in the manufacturers technical product manual. Excessive airflows and/or pressures could result in permanent damage and/or malfunction of the damper.

#### **Maintenance:**

1. Keep the damper clean and free from any contamination.
2. Where possible operate the blades against airflow to ensure easy, free movement without distortion or stress of the linkage.
3. Periodic inspection should be made of any seals that have been fitted to the damper, to ensure efficient control and operation.
4. It is recommended within normal preventative maintenance procedures for the blades and inner casings to be cleaned annually, with specific attention being made to ensure all spindles, bushes and linkage mechanism are clean and rotate freely.
5. The time period can be ascertained by experience or local regulations, but should not exceed a twelve month interval. Inspection should be carried out more frequently where excessive dust or dirty conditions prevail.
6. Normal lubrication should only be made to exposed spindles / bushes and operating linkages outside of the airflow. Excessive lubrication will attract dust and could fail or impede the operation of the damper.

# **BD Series Backdraft Dampers**

## **Installation, Maintenance and Operating Instructions**

**Models: Flangefit, Framefit and Spigotfit**

*Page 2 Continued...*

### **Operation:**

1. These dampers are primarily designed to relieve a build-up of pressure within the ductwork or used as a non-return valve to ductwork systems.
2. It is assumed that the airflow through the damper is filtered and environmentally controlled, with regard to humidification and corrosive atmospheres to national and international specifications.

### **National and International Specifications :**

1. The B.D. Series Control Damper is designed and manufactured for use as described in the HVCA Ductwork Specification DW144, and as Eurovent 2/2.
2. This product does conform to other National and international specifications not mentioned above, B.S.B.'s sales office can confirm detail as required.

### **Recommended Spares :**

1. Replacement Brush Seal.

It is always recommended that if either the specifying authority, the installer or the user has any doubts with regard to the product selection and / or suitability to the application, then contact to the following office is advised.

**B.S.B. Engineering Services Ltd.**

**(Technical Sales Department).**

**Unit E , Tribune Drive,**

**Trinity Trading Estate,**

**Sittingbourne.**

**Kent ME10 2PD.**

**Tele # +44 (0) 1795 422609.**

**Fax # +44 (0) 1795 429543.**

**Email: [sales@bsb-dampers.co.uk](mailto:sales@bsb-dampers.co.uk)**

**[www.bsb-dampers.co.uk](http://www.bsb-dampers.co.uk)**